

Follow Energia Core instructions to Step 23
then remove flanged pin from step 4 and
replace the 4 engine subassembly with this engine block



